



Apply the installation template



Drill holes in the corners



Saw on the line



Slip in the hatch from the outside



slide up and tighten the inner frame